

Controlling the Heat at MS-P

New split units have been installed in the Wood and Metal Shops in Purcellville.

Both units respond to Alexa commands, but you must be in the Green Room in order to give these commands. The Alexa device is currently located on top of the Desktop computer.

You may use the following commands to turn on the Heat in the Shops

For the Wood shop:

Say, "Alexa, Wood Shop Heat On"

For the Metal shop:

Say, "Alesa, Metal Shop Heat on"

Alexa should reply with "Ok"

When you are leaving and are the last person in the shop (or at any point), to turn off the heat

Say, "Alexa, Wood Shop Heat Off"

or

"Alexa, Metal Shop Heat Off"

If you are at home, ready to go to one of the shops, and you would like for the shop to warm up while you are driving, you can visit the following web site and click on the button for the shop that you would like to warm up.

<https://sites.google.com/makersmiths.org/heatmsp>

Notes:

The temperature for the Wood and Metal shop is fixed at 68 degrees. The temperature is automatically set back at 9pm each evening to 62 degrees. If you are in the Wood or Metal Shop after that time and need heat you will have to go to the Green Room and ask Alexa to turn the heat on again ("Alexa, Wood/Metal Heat On").

You should no longer use the Propane heater in the wood shop.